

15 bbl. DNV Waste Disposal Container

Liquid Depth (inches)	Barrels	Air Gap (inches)
1	0.50	30
2	1.00	29
3	1.49	28
4	1.99	27
5	2.49	26
6	2.98	25
7	3.48	24
8	3.98	23
9	4.47	22
10	4.97	21
11	5.47	20
12	5.97	19
13	6.46	18
14	6.96	17
15	7.46	16
16	7.95	15
17	8.45	14
18	8.95	13
19	9.45	12
20	9.94	11
21	10.44	10
22	10.94	9
23	11.43	8
24	11.93	7
25	12.43	6
26	12.93	5
27	13.42	4
28	13.92	3
29	14.42	2
30	14.91	1

NOTE: BOX MUST HAVE 1 INCH AIR GAP TO
KEEP FLUIDS FROM LEAKING THOUGH
THE PRESSURE RELIEF VALVE.